# SERVICES FOR MAINS GAS BBQS, UK

NG LPG

Instructions for Natural Gas (mains gas) ONLY

## WHAT IS THE PROCESS?

1

**Your gas engineer:**
Runs the mains gas pipework to the unit

2

**Grillo install team:**
Install your outdoor kitchen units

3

**Your gas engineer:**
Makes the final connection between mains gas pipe & BBQ


## WHAT DO GRILLO SUPPLY?

Note: The gas hose **will not** be connected to the BBQ by the installers as this needs to be completed by a **Certified Gas Engineer**. The yellow gas pipe will be supplied by us for the gas engineer to connect.




## MAINS GAS POSITIONING

**Example install diagram:**
Large units are 1200 x 610mm.
Small units are 610 x 610mm.




## PIPEWORK ROUTING OPTIONS


NG LPG

Instructions for Natural Gas (mains gas) ONLY

# *Option 1*

Run the mains gas pipework though the ground to the centre of the gas BBQ unit.









Drawings not to scale

# *Option 2*

Run the pipework in through the back of the unit by removing the cut-out in the lower rear fascia, as shown.





Drawings not to scale


*The height variation is for adjustment in the cabinet feet.

# *Option 3*

Instructions for Natural Gas (mains gas) ONLY

Run the pipework through the back of the unit by completely removing the rear fascia.




Drawings not to scale

*The height variation is for adjustment in the cabinet feet.

---

## BULL BBQ GAS CONNECTION, TO BE COMPLETED BY CERTIFIED GAS ENGINEER ONLY

Start by removing the BBQ from the unit and rolling it onto its back so you have access to the underside.



**1.** Gas connection pack to connect Bull BBQ



**2.** Connection point beneath the BBQ. Note the installed adapter, circled, will need to be removed



**3.** Unscrew the regulator to allow for easier access when connecting fittings



**4.** Remove the existing adaptor and fit the adapter supplied with the yellow hose



**5.** Connect the yellow hose



**6.** Reattach the regulator and hose to the BBQ



**7.** Connect the shut off valve to the flexible hose. This can now be connected to the mains gas supply